



Excess ozone out-use supplied white pinch valve w/black tubing normally closed- use as needed to regulate 0-3PSI on the gauge.

OZONE IN – use black tubing

Water in from aquarium

Muffler diffuser for Ozone-fill w/carbon.

Gauge should be 0-3 PSI-you may not see pressure here if valves are wide open.

Water out to aquarium.

**UMC4100Z**

**OZ618**

**OZMAN**

Valve for draining reactors

Water out to aquarium \*\*Use valve here to regulate the water flow output and PSI

